



Analog 3-Hand - SR5008, SR5010, SR5040, SR5042, SR5043, SR5048, SR5105, SR5106, SR5110, SR5113, SR5114, SR5120, SR5122, SR5123, SR6022, SR6023, SR6024, SR6026, SR6027, SR6028, SR6029, SR6032, SR6034, SR6035, SR6071, SR6073, SR6075, SR6079, SR6080, SR6091, SR6092, SR6122, SR6123, SR6144, SR6145, SR6147, SR6148, SR6151, SR6152, SR6153, SR6154, SR6164, SR6165, SR6172, SR9020, SR9021, SR9022, SR9023, SR6183, SR6177, SR6178, SR6179, SR6180, SR6181, SR6182, SR5125, SR5127, SR5126, SR6176, SR5128, SR5129, SR5130, SR5131, SR5134, SR5135, SR5136, SR5137, SR5140, SR5141, SR5143, SR5145, SR6189, SR6190, SR6191, SR6192, SR6196, SR6197, SR6198, SR6199, SR6200, SR6201, SR6207, SR6209, SR6212, SR6213, SR6214, SR9028, SR9029, SR9030, SR9033, SR9034, SR9035, SR9036, SR9037, SR9038, SR9039, SR9040



Time Setting

1. Pull the crown out to position 2.
2. Turn the crown to set the correct time.
3. Push the crown back to position 1.

**Analog 3-Hand Date - SR5021, SR5022, SR5076, SR6049,
SR6050, SR6052, SR6053, SR6101, SR6169, SR6170,
SR6171, SR5138, SR5139**




Date Setting

1. Pull the crown out to position 2.
2. Turn the crown either clockwise or counter-clockwise and set the date for the previous day. The direction that moves the date varies on different watch models.

Time Setting

1. Pull the crown out to position 3.
2. Turn the crown counter-clockwise to advance the time and continue until the day changes to the present day.
3. Set the correct time.
4. Push the crown back to position 1.

VJ53A Day/Date Watch - SR5000, SR5002, SR5003,



Date Setting

1. Pull the crown out to position 2.
2. Turn counter-clockwise and set the date for the previous day.


Day Setting

With crown still in position 2, turn clockwise and set the day for the previous day.

Time Setting

1. Pull the crown out to position 3.
2. Turn counter-clockwise to advance the time and continue until the day/date changes to the present day.
3. Set the correct time.
4. Push the crown back to position 1.

**HFT-183 Analog Digital - SR6001, SR6002, SR6004,
SR6166, SR6167,**



12/24H Format

- In Time mode, press "B" to toggle between 12 and 24H time formats.

EL Backlight

- Press "C" to make display light up for 3 seconds

Alarm and Chime On/Off

1. In Time mode, press and hold "C", and also press "D" to turn Alarm ON/OFF.
2. To test Alarm sound, press "C" then hold "D". Alarm will beep.
3. Press "C" to turn Alarm sound OFF.
4. To activate/deactivate Chime, press and hold "C", and also press "B" too
5. Release "C" to return to Normal Time mode.

Setting the Time

1. In Time mode, press "B" three times, day and seconds will flash.
2. Press "D" to reset seconds to "00".
3. Press "C" once to select minutes, then press "D" to advance the minutes.
4. Press "C" twice to select hour, then press "D" to advance the hour.
5. Press "C" three times to select month or date, then press "D" to advance.
6. Press "C" four times to select month or date, then press "D" to advance.
7. Press "C" five times to select day, then press "D" to advance.
8. Press "C" once to exit Time Setting mode.

12/24H Time

1. Press "B" three times, then press "C" to select AM/PM and 12/24H format. Press "D" to advance.
2. Press "B" to exit 12/24H Setting mode.

Setting the Alarm

1. In Time mode, press "B" twice to select day and hour, then press "D" to advance.
2. Press "C" to switch to minute setting, then press "D" to advance minutes.
3. Press "B" to exit Alarm Setting mode.

Stopwatch

1. In Time mode, press "B" to enter Stopwatch mode.
2. Press "D" to start/stop Stopwatch.
3. For Split Time, press "C" while Stopwatch is counting. To exit Split Time, press "C" again.
4. Press "D" to stop Stopwatch counting, then "C" to reset.

HFT-2344 DIGITAL - SR1032, SR1033

EL BACKLIGHT



**STOPWATCH
START/STOP**

MODE

**STOPWATCH
RESET**

Switching Between Modes

- Press "B" to toggle through modes in the following order: Time, Alarm, Stopwatch, Countdown Timer

EL Backlight

- To make the display glow for 3 seconds, press "A".

Setting the Time

1. In Time mode, press and hold "C" for 3 seconds to select seconds. Press "D" to reset seconds to "00".

2. Press "B" to select minutes, press "D" to advance minutes.
3. Press "B" to select hour, press "D" to advance hour.
4. Press "B" to select 12/24H, press "D" to toggle to 12 or 24H format.
5. Press "B" to select month, press "D" to advance month.
6. Press "B" to select date, press "D" to advance date.
7. Press "B" to select day, press "D" to advance day.
8. Press "C" to exit Time Setting mode.

Alarm/Chime Setting Mode

1. Press "D" to toggle Alarm and or Chime ON/OFF.
2. Press and hold "C" for 3 seconds to enter Alarm setting mode, hour will be flashing. Press "D" to advance hour.
3. Press "B" to select minutes, then press "D" to advance minutes.
4. Press "C" to exit Alarm Setting mode

Stopwatch

1. Press "D" to start/stop Stopwatch.
2. With Stopwatch running, press "C" to enter/exit Split Time mode.
3. Press "D" to stop Stopwatch.
4. Press "C" to reset Stopwatch.

Countdown Timer

1. In Countdown Timer mode, Press and hold "C" for 3 seconds to enter Timer Setting mode. Hours will flash, then press "D" to advance hours.
2. Press "B" to select minutes, then press "D" to advance.

3. Press "C" to exit Timer Setting mode and return to Countdown Timer readout.
4. Press "D" to start/stop the Timer.
5. With Timer stopped, press "C" to reset.

Dual Time Mode (Setting Secondary Time, T2)

1. In Time mode, press "D" to toggle between primary time and secondary time (T2) readouts.
2. To enter T2 Setting mode, toggle to T2, then press and hold "C" for 3 seconds. Minutes will flash, then press "D" to advance minutes.
3. Press "B" to select hour, then press "D" to advance hour.
4. Press "C" to exit T2 Setting Mode.

MD11258T(R) Y121E4 ANALOG DIGITAL - SR1040, SR1042

**STOPWATCH
RESET**



**STOPWATCH
START/STOP**

MODE B

EL BACKLIGHT C

Setting Analog Time

- Pull out crown and turn to adjust hour and minute hands.
- Push crown back to normal position once time is set.

Switching Between Modes

- Press "B" to toggle through modes in the following order: Time, Alarm, Stopwatch, Dual Time

EL Backlight

- To make display glow for 3 seconds, press "C"

Setting the Time

1. In Time mode, press and hold "A" until seconds flash, then press "D" to reset seconds to "00".
2. Press "B" select hour, then press "D" to advance. Holding "D" will advance hour at a faster speed.
3. Repeat step 2 to set Minutes, Month, Date, Day, 12/24H Format.
4. Press "A" to exit Time Setting mode.

Alarm and Chime ON/OFF

- In Alarm mode, press "D" to turn on/off the Alarm and Chime sound in the following sequence: Alarm and Chime OFF, Alarm ON, Chime ON, Alarm and Chime ON.
- Alarm sounds at the preset time for 60 seconds if sound is set to ON. Pressing any button will silence it.

Setting the Alarm

1. In Alarm mode, press "A" to select hour, then press "D" to advance the hour. Holding "D" will advance hour at a faster speed.
2. Repeat step 2 to set minutes
3. Press "A" to exit Alarm Setting mode.

Stopwatch

1. In Stopwatch mode, press "D" to start/stop counting.
2. Press "A" to reset Stopwatch.
3. In Stopwatch counting mode, press "A" to enter/exit Split Time.
4. Press "D" to stop Stopwatch, and "A" to exit Stopwatch mode.

Setting Dual Time

1. In Dual Time mode, press "A" to select hour, then press "D" to advance hour. Holding "D" will advance the hour at a faster speed.
2. Press "B" to select minutes, then press "D" to advance minutes. Holding "D" will advance the hour at a faster speed.
3. Press "A" to exit Dual Time Setting Mode.

MD08181N DIGITAL - SR1006, SR1008

**STOPWATCH
RESET**



**D STOPWATCH
START/STOP**

MODE B

C EL BACKLIGHT

Switching Between Modes

- Press "B" to toggle through modes in the following order: Time, Alarm, Stopwatch, Dual Time

EL Backlight

- To make display glow for 3 seconds, press "C"

Switching Between 12/24H Formats

- Press "A" to toggle between 12H or 24H readout formats

View Calendar

- Press and hold "D" to display Year, Month, Date

Setting the Time

1. In Time mode, press and hold "A" until seconds flash, then press "D" to reset to "00".
2. Press "B" to select hour, then press "D" to advance hour. Holding "D" will advance hour at a faster speed.
3. Repeat step 2 to set remaining features in the following order: Minutes, Year, Month, Date. Day of week will automatically set.
4. Press "A" to exit Time Setting.

Alarm and Chime ON/OFF

- In Alarm mode, press "D" to turn ON/OFF Alarm and Chime in the following order: Alarm and Chime OFF, Alarm ON, Chime ON, Alarm and Chime ON.
- Alarm sounds at preset time each day for 60 seconds. Pressing any button will silence it.

Setting the Alarm

1. In Alarm mode, press "A" to select hour, then press "D" to advance hour. Holding "D" will advance hour at a faster speed.
2. Press "B" to select minutes, then press "D" to advance minutes. Holding "D" will advance hour at a faster speed.
3. Press "A" to exit Alarm Setting mode.

Stopwatch

1. In Stopwatch mode, press "D" to start/stop the Stopwatch.
2. Press "A" to reset the Stopwatch.

3. In Stopwatch counting mode, press "A" to enter/exit Split Time.
4. Press "D" to stop Stopwatch, and "A" to reset.

Setting Dual Time

1. In Dual Time mode, press "A" to select hour, then press "D" to advance hour. Holding "D" will advance hour at a faster speed.
2. Press "B" to select minutes, then press "D" to advance minutes.
3. Press "A" to exit Dual Time Setting mode.

MD7133 DIGITAL - SR2011

**STOPWATCH
RESET**



**STOPWATCH
START/STOP**

MODE

EL BACKLIGHT

Switching Between Modes

- Press "B" to advance through the different modes: Time, Alarm, Stopwatch, Dual Time 12/24H Format
- In Time mode, press "A" to toggle between 12 and 24H time formats.

Calendar

- In Time mode, press and hold "D" to display Year, Month and Date.

EL Backlight

- Press "C" to make display light up for 3 seconds

Setting the Time

1. In Time mode, press and hold "A" to select seconds (seconds will flash).
2. Press "D" to reset seconds to "00".
3. Press "B" to select hour, then press "D" to advance the hour. Holding "D" will advance the hour at a faster speed.
4. Repeat step 3 to finish setting time in the following order: Seconds, Hour, Minute, Year, Month, Date

Setting the Alarm

1. In Alarm mode, press "A" to select hour, then press "D" to advance the hour. Holding "D" will advance the hour at a faster speed.
2. Press "B" to select minutes, then press "D" to advance the minutes. Holding "D" will advance the minutes at a faster speed.
3. Press "A" to exit Alarm Setting mode.

Alarm and Chime On/Off

- In Alarm mode, press "D" to turn on/off the alarm and chime in the following order: Alarm/Chime Off, Alarm On, Chime On, Alarm/Chime On

Stopwatch

1. In Stopwatch mode, press "D" to start elapsed time, press "D" again to stop elapsed time.
2. Press "A" to reset stopwatch.
3. For Split Time, press "D" to start Stopwatch, then press "A" to display Split Time (Stopwatch timing continues internally).
4. Press "A" to clear the Split Time and to continue Stopwatch.
5. Press "D" to stop the Stopwatch.

Dual Time

1. In Dual Time mode, press "A" to select hour., then press "D" to advance the hour. Holding "D" will advance the hour at a faster speed.
2. Press "B" to select minutes, then press "D" to advance the minutes. Pressing once advances minutes by "30".
3. Exit Dual Time Setting by pressing "A".

ED0368 DIGITAL - SR2021, SR2022, SR2027



Setting the Time

1. Press "A" to advance the Date. Holding "A" advances Date at a faster speed.
2. Press "B" to advance the Hour. Holding "B" advances Hour at a faster speed.
3. Press "C" to advance the Minutes. Holding "C" advances Minutes at a faster speed.

EL Backlight

- Press "D" to make display glow for 3 seconds.

HFT-3454 DIGITAL - SR1019, SR1022, SR1117, SR1121

EL BACKLIGHT A

**D STOPWATCH
START/STOP**



MODE B

C STOPWATCH RESET

Switching Between Modes

- Press "B" to toggle through modes in the following order: Time, Stopwatch, Alarm, Time Setting

EL Backlight

- To make display glow for 3 seconds, press "A"

Setting the Time

1. In Time Setting mode, press "C" to select seconds, then press "D" to reset to "00".
2. Press "C" to select hour, then press "D" to advance the hour. ("H" displayed represents 24H format, "A" and "P" represent 12H format.)
3. Repeat step 2 to set Minutes, Month, Day, and Date.
4. Press "B" to exit Time Setting mode.

Alarm and Chime ON/OFF

1. In Alarm mode, press "D" to toggle through settings to turn Alarm and Chime
 - Alarm sounds at the preset time for 60 seconds. Press any button to silence it.
2. When Snooze function is on, Alarm will sound again 5 minutes later for 20 seconds.

Setting the Alarm

1. In Alarm mode, press "C" to select hour or minute, then press "D" to advance the selected item
2. Press "C" to exit Alarm Setting mode.

Stopwatch

1. In Stopwatch mode, press "D" to start/stop Stopwatch.

2. Press "C" to reset Stopwatch.
3. In Stopwatch counting mode, press "C" to enter/clear Split Time.
4. Press "D" to exit Split Time.
5. Press "B" to exit Stopwatch mode. If Stopwatch is not stopped before doing this, it will keep counting in the background.

MS057 - SR2016, SR2017, SR2019, SR2020, SR2063, SR2099

STOPWATCH RESET A

D **STOPWATCH START/STOP**

MODE B

C **EL BACKLIGHT**



Switching Between Modes

- Press "B" to advance through the different modes: Time, Alarm, Stopwatch, Dual Time

12/24H Format

- In Time mode, press "A" to toggle between 12 and 24H time formats.

Calendar

- In Time mode, press and hold "D" to display Year, Month and Date.

EL Backlight

- Press "C" to make display light up for 3 seconds

Setting the Time

1. In Time mode, press and hold "A" to select seconds (seconds will flash).
2. Press "D" to reset seconds to "00".
3. Press "B" to select hour, then press "D" to advance the hour. Holding "D" will advance the hour at a faster speed.
4. Repeat step 3 to finish setting time in the following order: Seconds, Hour, Minute, Year, Month, Date
5. Press "A" to exit time setting mode.

Setting the Alarm

1. In Alarm mode, press "A" to select hour, then press "D" to advance the hour. Holding "D" will advance the hour at a faster speed.
2. Press "B" to select minutes, then press "D" to advance the minutes. Holding "D" will advance the minutes at a faster speed.
3. Press "A" to exit Alarm Setting mode.

Alarm and Chime On/Off

- In Alarm mode, press "D" to turn on/off the alarm and chime in the following order: Alarm/Chime Off, Alarm On, Chime On, Alarm/Chime On

Stopwatch

1. In Stopwatch mode, press "D" to start elapsed time, press "D" again to stop elapsed time.
2. Press "A" to reset stopwatch.
3. For Split Time, press "D" to start Stopwatch, then press "A" to display Split Time (Stopwatch timing continues internally).
4. Press "A" to clear the Split Time and to continue Stopwatch.
5. Press "D" to stop the Stopwatch.

Dual Time

1. In Dual Time mode, press "A" to select hour., then press "D" to advance the hour. Holding "D" will advance the hour at a faster speed.
2. Press "B" to select minutes, then press "D" to advance the minutes. Pressing once advances minutes by "30".
3. Exit Dual Time Setting by pressing "A".

08407-YP(MD08172)-A4-E1 - SR1079, SR1080



toggling through All Modes

- Press "B" to toggle through all modes in the following order: Time/Stopwatch/Countdown/Alarm

EL Backlight

- In any mode, press "C" to illuminate the display for 3 seconds.

Setting the Time and Calendar

- 1.) 12/24 Hour Format: In the timekeeping mode, press "D" to switch between 12 and 24 hour formats.
- 2.) Time: In the timekeeping mode, press and hold "A" until seconds begin to flash.
- 3.) Press "D" to reset the seconds
- 4.) Press "B" to change to the next selection.
- 5.) Press "D" to increase the number. Press and hold to increase speed.

- 6.) Repeat steps 3 & 4 in the following sequence: Seconds/Hour/Minutes/Year/Month/Date
- 6.) When all settings are complete, press "A" to confirm. (The day of the week is automatically displayed in accordance with the month and date setting).

Stopwatch

- 1.) Lap Time: In the stopwatch mode, press "D" to start the stopwatch
- 2.) To stop the stopwatch, press "D" again
- 3.) Press "A" to reset the stopwatch
- 4.) Split Time: In the stopwatch mode, press "D" to start the stopwatch
- 5.) Press "A" to display the split time, the stopwatch time will continue internally
- 6.) Press "A" to clear the split time and to continue to time measurement.
- 7.) Repeat step 2 & 3 to measure the multi split time.
- 8.) Press "D" to stop the stopwatch.

Countdown

- 1.) When the countdown reaches zero, the alarm sounds for about 60 seconds. Press any button to silence it.
- 2.) Setting Countdown Time: In the countdown mode, press "A" until hour begins to flash (flash indicates setting mode).
- 3.) Press "D" to increase the hour. Press and hold to increase speed.
- 4.) Press "B" to change to next selection.
- 5.) Press "D" to increase. Press and hold to increase speed.

- 6.) Repeat steps 3 & 4 to select countdown 6n the following sequence:
Hour/Minutes/Seconds
- 7.) When all settings are complete, press "A" to confirm.
- 8.) Use Countdown Time: Press "D" to start the countdown.
- 9.) To pause the countdown, press "D" again.

Setting the Alarm

- 1.) The alarm sounds at the present time each day for about 60 seconds. Press any button to silence it.
- 2.) Alarm & Chime: In the alarm mode, press "C" to select Chime/Alarm1/Alarm2/Alarm3/Alarm4/Alarm5
- 3.) In Chime state, press "D" to on/off the chime.
- 4.) In the Alarm1-Alarm5 state, press "D" to on/off the alarm.
- 5.) Alarm Setting: In the alarm mode, press "A" to flash the hour. The alarm indicator will appear (flashing indicates setting mode).
- 6.) Press "D" to increase the hour. Press and hold to increase speed.
- 7.) Press "B" to select the minutes.
- 8.) Press "D" to increase the minutes. Press and hold to increase speed.
- 9.) When all settings are complete, press "A" to confirm.
- 10.) Setting and operation of Alarm1-Alarm5 are the same.

Setting Analog Time

- 1.) Pull out the crown, turn it to adjust the hour and minute hands.
- 2.) Once time has been set, push crown back in.

15678-YP(MD15360)-A4A4-E - SR1082, SR1083



Toggling through All Modes

- Press "B" to toggle through all modes in the following order: Time/Stopwatch/Data/Countdown/Alarm/Dual Time

EL Backlight

- In any mode, press "C" to illuminate the display for 3 seconds.

Setting the Time and Calendar

- Calendar: In the timekeeping mode, press and hold "D" to display: Year/Month/Date
- Time: In the timekeeping mode, press and hold "A" until seconds begin to flash.
- Press "C" or "D" to reset the seconds
- Press "B" to change to the next selection.

- Press "D" to increase the number. Press and hold to increase speed. Press "C" to decrease the number. Press and hold to increase speed.
- Repeat steps 3 & 4 in the following sequence: Seconds/Hour/Minutes/Year/Month/Date/12/24H Format
- When all settings are complete, press "A" to confirm. (The day of the week is automatically displayed in accordance with the month and date setting).

Stopwatch

- Lap Time: In the stopwatch mode, press "D" to start the stopwatch
- To stop the stopwatch, press "A"
- Press "A" again to reset the stopwatch
- Split Time: In the stopwatch mode, press "D" to start the stopwatch
- Press "D" again to display the split time, the stopwatch time will continue internally. After 2 seconds, the display will automatically show running time.
- Repeat step 2 to measure the multi split time.
- Press "A" to stop the stopwatch.

Data

- In the data mode, the watch will display the time of the first lap.
- Press "D" to forward browse the times.
- Press "C" to backward browse the times.
- Split: In the data mode, press "A" to display the time of first SPL.
- Press "D" to forward browse the times.
- Press "C" to backward browse the times.

- Press "A" to enter the stopwatch mode in the browse split time state.

Countdown

- When the countdown reaches zero, the alarm sounds for about 60 seconds. Press any button to silence it.
- Setting Countdown Time: In the countdown mode, press "A" until hour begins to flash (flash indicates setting mode).
- Press "D" to increase the hour. Press and hold to increase speed.
- Press "B" to change to next selection.
- Press "D" to increase. Press and hold to increase speed.
- Repeat steps 3 & 4 to select countdown in the following sequence:
Hour/Minutes/Seconds
- When all settings are complete, press "A" to confirm.
- Use Countdown Time: Press "D" to start the countdown.
- To pause countdown, press "A." Then press "D" to start again.

Setting the Alarm

- The alarm sounds at the present time each day for about 60 seconds. Press any button to silence it.
- Alarm & Chime: In the alarm mode, press "A" to select Chime/ Alarm1/Alarm2/Alarm3/Alarm4/Alarm5
- In Chime state, press "D" to on/off the chime.
- In the Alarm1-Alarm5 state, press "D" to on/off the alarm.
- Alarm Setting: In the alarm mode, press "A" to flash the hour. The alarm indicator icon will appear (flashing indicates setting mode).

- Press "D" to increase the hour. Press and hold to increase speed. Press "C" to decrease the hour. Press and hold to increase speed.
- Press "B" to select the minutes.
- Press "D" to increase the minutes. Press and hold to increase speed. Press "C" to decrease the minutes. Press and hold to increase speed.
- When all settings are complete, press "A" to confirm.
- Setting and operation of Alarm1-Alarm5 are the same.

Dual Time

- In the dual time mode, press "A" until hour begins to flash (flash indicates setting mode).
- Press "D" to increase the hour. Press and hold to increase speed. Press "C" to decrease the hour. Press and hold to increase speed.
- Press "B" to select the minutes.
- Press "C" or "D" to change the minutes (one press will increase by 30 minutes).
- When all settings are complete, press "A" to confirm.

6 digit + QA HFT-2637 - SR1073, SR1074, SR1119



Toggle through All Modes

- Press "B" to toggle through all modes in the following order: Time/Stopwatch/Alarm/Time Setting

EL Backlight

- Press "A" to illuminate the display for 3 seconds.

Setting the Time and Calendar

1. In Time Setting Mode, press "D" to reset seconds to "00".
2. Press "C" to select settings in the following order: Minute/Hour/Day/Month/Day of Week/Seconds
3. Press "D" to advance each selection. (When changing Hour selection, "H" will to indicate 24 Hour format; "A" or "P" will indicate 12 Hour Format.)
4. When all settings are complete, press "B" to confirm.

Setting the Alarm

1. From normal time mode, press "C" to select "Hour" or "Minute".
2. Press "D" to adjust, and "B" to confirm.
3. From normal time mode, hold down "C" and press "D" to toggle through Alarm/Chime ON/OFF settings.
4. When Alarm sounds, press "C" to stop and "D" to Snooze. Alarm will sound again in 5 minutes.

Stopwatch

1. In Stopwatch Mode, press "D" to Start/Stop, then press "C" to reset.
2. To run Stopwatch in the background, press "B" to return to Normal Time Mode.
3. Then press "D" in Stopwatch Mode to stop counting. Press "C" to reset Stopwatch.

Setting Analog Time

1. Pull crown out to first click, then turn it to set the hour and minute hands to the desired time.
2. Push crown back to normal position.

12 Digit QA HFT-2636 - SR1077



Toggle through All Modes

- Press "B" to toggle through all modes in the following order: Time/ Stopwatch/ Alarm/Time Setting

EL Backlight

- Press "A" to illuminate the display for 3 seconds.

Setting the Time and Calendar

1. In Time Setting Mode, press "D" to reset seconds to "00".
2. Press "C" to select settings in the following order: Hour/Minute/ Month/Date/Day of Week
3. Press "D" to advance each selection.
4. When all settings are complete, press "B" to confirm.

Setting the Alarm

1. In Alarm Mode, press "D" to toggle through Alarm/Chime ON/ OFF settings.
2. In Alarm Mode, press "C" to select "Hour" or "Minute" and "D" to advance the setting. Press "B" to confirm.

Stopwatch

1. In Stopwatch Mode, press "D" to Start/Stop, then press "C" to reset.

053 -BJ3475 - SR1069, SR1070



Toggle through All Modes

- Press "B" to toggle through all modes in the following order: Time/ Stopwatch/Alarm/Dual Time

EL Backlight

- Press "A" to illuminate the display for 3 seconds.

Setting the Time and Calendar

1. In Time Setting Mode, press "C" to reset seconds to "00".
2. Press "C" to select settings in the following order: Hour/Minute/ Month/Date/Day of Week/Second
3. Press "D" to advance each selection.
4. When all settings are complete, press "B" to confirm and exit setting mode.

Setting 12H/24H Format

1. In Time Setting Mode with Hour selected, press "D" to toggle through hours.
2. "A" and "P" indicate AM and PM for 12H readout, and "H" indicates 24H readout.

Setting the Alarm

1. In Alarm Mode, press "D" to toggle through Alarm/Chime ON/OFF settings.
2. In Alarm Mode, press "C" until hour flashes, and press "D" to advance. (Hold down "D" to advance at higher speed.)
3. Press "C" to select minutes, and "D" to advance.
4. Press "B" to confirm and exit setting mode.
5. Alarm sounds for 20 seconds, press "B" to turn Snooze function ON/OFF. Press "C" or "D" to silence Alarm. When Alarm is Snoozed, it will sound again in 5 minutes.

Stopwatch

1. In Stopwatch Mode, press "D" to Start/Stop, then press "C" to reset.
2. To run Stopwatch in the background, press "B" to return to Normal Time Mode.
3. In Stopwatch Mode with stopwatch running, press "C" to start split time counting, press "C" again to exit split time counting.
4. Then press "D" exit Split Time and stop counting. Press "C" to reset Stopwatch.

**HFT-3338 - SR6065, SR6066, SR6067, SR6070, SR6168,
SR6010, SR6012, SR6009, SR6013, SR6188, SR6205,
SR6206**



Toggle through All Modes

- Press "B" to toggle through all modes in the following order: Time/ Stopwatch/ Alarm/Time Setting

EL Backlight

- Press "A" to illuminate the display for 3 seconds.

Setting the Time and Calendar

1. In Time Setting Mode, press "C" to reset seconds to "00".
2. Press "D" to select settings in the following order: Hour/Minute/ Month/Date/Day of Week (when setting the Hour, "H" will appear in 24Hour format, and "A" and "P" will appear for 12Hour format.)
3. Press "C" to advance each selection.
4. When all settings are complete, press "B" to confirm.


Setting the Alarm

1. In Alarm Mode, press "C" to toggle through Alarm/Chime ON/OFF settings.
2. In Alarm Mode, press "D" to select "Hour" or "Minute" and "C" to advance the setting. Press "B" to confirm.
3. When Alarm sounds, press "C" or "D" to stop it, press "B" to snooze and alarm symbol will flash. (When Snooze is ON, Alarm will sound 5 minutes later, and stop after 20 seconds.)

Stopwatch

1. In Stopwatch Mode, press "C" to Start/Stop, then press "D" to reset.
2. To enter Split Time, press "D" while Stopwatch is running, then press "C" to exit Split Time and stop counting.
3. Press "D" to display all count records, and then press "D" again to reset Stopwatch.
4. To operate Stopwatch in the background, press "B" while counting.

HFT-3455 - SR5071, SR5072, SR5073, SR5149, SR5151



Toggle through All Modes

- Press "B" to toggle through all modes in the following order: Time/Chronograph/Alarm/Time Setting

EL Backlight

- Press "A" to illuminate the display for 3 seconds.



Setting the Time and Calendar

1. In Normal Time Mode, press "B" to toggle to Time Setting Mode and seconds will flash. Press "D" to reset seconds to "00".
2. Press "C" to select time settings in the following order: Hour/Minute/Month/Day/Day of Week/Second
3. Press "D" to advance each selection.
4. When setting the hour, "H" will display indicating the hour will be set in 24-Hour Format, or "A"/"P" will display to indicate the hour will be set in 12-Hour format.
5. When all settings are complete, press "B" to confirm and return to Normal Time Mode.

Setting the Alarm

1. In Normal Time Mode, press "B" to toggle to Alarm Mode.
2. Press "C" select Hour, then press "D" to adjust it. Repeat to set Minute.
3. Press "C" to confirm Alarm setting, then press "B" to return to Normal Time Mode.

Using Alarm and Chime

1. In Alarm Mode, press "D" to toggle Alarm  and/or Chime  ON/OFF. When Alarm is set to ON, Snooze function is also on. (You can Snooze the Alarm for 5 minutes at a time, and Alarm stops sounding after 20 seconds.)

Stopwatch

1. In Stopwatch Mode, press "D" to Start/Stop, then press "C" to reset.
2. To view Normal Time while Stopwatch is running in background, press "B".
3. To enter Split Time while in Stopwatch Mode, start the Stopwatch by pressing "D", then press "C" while it is running to split the count, then press "C" again to display Split Time.
4. To exit Split Time and stop counting, press "D".
5. Press "C" to clear to zero.

DIGITAL MD15370T - SR5116, SR5118



Toggling through All Modes

- Press "B" to toggle through modes in the following order: Normal Time/Stopwatch/Alarm/Time Setting

EL Backlight

- In any mode, press "C" to illuminate the display for 3 seconds.

Setting the Time and Calendar

1. Toggle to Time Setting Mode, and seconds will flash.
2. Press "D" to reset the seconds.
3. Press "A" to select settings in the following order: Minutes/Hour/Day/Month/Week, then press "D" to increase the number. (Press and hold "D" to increase the setting at a faster rate.)
4. When setting "Hour", 12/24H format can be selected.

5. Press "B" to exit Time Setting Mode.

Setting the Alarm

1. In Alarm Mode, press "D" to adjust "Hour".
2. Press "A" to select "Minutes" and "D" to adjust.
3. Press "B" to return to Normal Time Mode.
4. When Alarm sounds, press "A" to stop it.
5. To snooze the Alarm, press "D". Alarm will sound again in 5 minutes.

Alarm/Chime

1. In Normal Time Mode, press and hold "A" to display the Alarm time.
2. Press "D" to toggle through turning Alarm/Chime ON/OFF.

Stopwatch

1. In Stopwatch Mode press "D" to start the stopwatch, press "D" again to stop.
2. Press "A" to reset to zero.
3. To count Split Time while in Stopwatch Mode with Stopwatch running, press "A".
4. To clear Split Time and continue counting main Stopwatch, press "A".
5. To run Stopwatch in background while in Normal Time Mode, press "D" to start Stopwatch, then "B" to return to Normal Time Mode.
6. Press "D" to stop the Stopwatch, then press "A" to reset to zero.

DIGITAL HFT-1658 - SR1037, SR1035, SR1038, SR1118, SR5107, SR5109, SR5144, SR5152



Toggle through All Modes

- Press "B" to toggle through modes in the following order: Normal Time/Alarm/Stopwatch/Time Setting

EL Backlight

- In any mode, press "C" to illuminate the display for 3 seconds.

12/24 Hour Format

- In Normal Time Mode, press "D" to switch between 12/24H time formats.

Setting the Time and Calendar

1. Toggle to Time Setting Mode, press "D" to seconds will flash.
2. Press "D" to reset the seconds.
3. Press "C" to select settings in the following order: Hour/Minutes/ Month/Day/Day of Week, then press "D" to increase the number.
4. Once complete, press and hold "B" to exit Time Setting Mode.

Setting the Alarm

1. In Alarm Mode, press "D" to turn Alarm and Chime ON/OFF.
2. In Alarm Mode, press "C", hours will flash indicating Alarm Setting Mode.
3. Press "D" to increase the hour.
4. Press "C" to select minutes, and press "D" to increase the number.
5. When all alarm settings are complete, press "C" to confirm and "B" to return to Normal Time Mode.

Stopwatch

1. In Stopwatch Mode press "D" to start the stopwatch, press "D" again to stop.
2. Press "C" to reset to zero.
3. To count Split Time while in Stopwatch Mode with Stopwatch running, press "C".
4. To exit Split Time and stop counting, press "D"
5. To run Stopwatch in background while in Normal Time Mode, press "D" to start Stopwatch, then "B" to return to Normal Time Mode.
6. Press "D" to stop the Stopwatch, then again to reset to zero.

DIGITAL J8403 - SR6126, SR6127, SR6141, SR6142, SR6143, SR6202



Toggling through All Modes

- Press "B" to toggle through modes in the following order: Normal Time/Stopwatch/Alarm/Time Setting

EL Backlight

- In any mode, press "A" to illuminate the display for 3 seconds.

Setting the Time and Calendar

1. Toggle to Time Setting Mode, and seconds will flash.
2. Press "D" to reset the seconds.
3. Press "C" to select settings in the following order: Minutes/Hour/Day/Month/Week, then press "D" to increase the number.
4. When setting "Hour", "H" indicates 24H format, "A" or "P" indicates 12H format.
5. Press "B" to exit Time Setting Mode.

Setting the Alarm

1. In Alarm Mode, press "C", to select "Hour" or "Minute" setting.
2. Press "D" to adjust the flashing item.
3. Press "C" to confirm settings, and press "B" to return to Normal Time Mode.
4. When Alarm sounds, press "C" to stop it.
5. To snooze the Alarm, press "D". Alarm will sound again in 5 minutes.

View Alarm and Calendar

- Press "C" to display Alarm, press "D" to display Date.

Alarm/Chime


1. Press C+D to turn Alarm ON/OFF. "⏰" indicates Alarm is ON.
2. Press C+B to turn Chime ON/OFF. When Chime is ON, all days of week are displayed on the screen.

Stopwatch

1. In Stopwatch Mode press "D" to start the stopwatch, press "D" again to stop.
2. Press "C" to reset to zero.
3. To count Split Time while in Stopwatch Mode with Stopwatch running, press "C".
4. To exit Split Time and stop counting, press "D".
5. To view display all times, press "C", to clear them press "C" again.
6. To run Stopwatch in background while in Normal Time Mode, press "D" to start Stopwatch, then "B" to return to Normal Time Mode.

7. Press "D" to stop the Stopwatch, then again to reset to zero.

DIGITAL BJ3059 - SR6158, SR6159



Toggle through All Modes

- Press "B" to toggle through modes in the following order: Normal Time/Seconds/ Alarm/Stopwatch

EL Backlight

- In any mode, press "A" to illuminate the display for 3 seconds.

Normal Time Mode

- Use the Normal Time Mode to set and view the current time and date.
- In Normal Time Mode, press "D" to view the current date. Release "D" to return to the Normal Time Mode.

Setting the Time and Calendar

1. In Normal Time Mode, press and hold "C" until minutes flash.

2. Press "D" to adjust minutes to desired setting.
3. Press "B" to select remaining settings in the following order: Hour/24Hour/Year/Month/Date, then press "D" to adjust each one.
4. Press "C" to exit Time Setting Mode.

Setting the Alarm

1. In Alarm Mode, press "C" and minutes will flash.
2. Press "D" to adjust the setting (press and hold "D" to adjust the setting at faster speed).
3. Press "B" to select Hour, press "D" to adjust.
4. Press "C" to exit Alarm setting state.

Alarm/Chime

1. In Alarm Mode, press "D" to toggle Alarm/Chime ON/OFF.
2. Alarm ON icon will appear at bottom of screen.
3. Continue pressing "D" to turn on Chime. Chime ON is indicated by all days of week appearing at top of screen.
4. Press "B" two times to toggle back to Normal Time Mode.

Stopwatch

1. In Stopwatch Mode press "D" to start the stopwatch, press "D" again to stop.
2. Press "C" to reset to zero.
3. Press "B" once to return to Normal Time Mode.

DIGITAL J8449 - SR2095, SR2096, SR2097, SR2098,



Toggle through All Modes

- Press "B" to toggle through modes in the following order: Normal Time/Stopwatch/Alarm/Time Setting Mode.

EL Backlight

- In any mode, press "A" to illuminate the display for 3 seconds.

Setting the Time and Calendar

1. In Time Setting Mode, seconds will flash. Press "D" to reset seconds to zero.
2. Press "C" to select remaining settings in the following order: Minute/ Hour/Day/Month/Week, then press "D" to adjust each one.
3. When setting Hour, "H" will display to indicate 24H format. "A" or "P" will display to indicate 12H format.
4. Press "B" to exit Time Setting Mode.

Setting the Alarm

1. In Alarm Mode, Hours will flash. Press "D" to adjust hours.
2. Press "C" to select Minutes and press "D" to adjust.
3. Press "B" to exit to Normal Time Mode.

Alarm

1. When Alarm sounds, press "C" to stop it.
2. Press "D" to toggle Snooze function ON/OFF.
3. When Snooze is ON, Alarm will sound again 5 minutes later.
4. Alarm will stop automatically after 1 minute.

Stopwatch

1. In Stopwatch Mode press "D" to start the stopwatch, press "D" again to stop.
2. Press "C" to reset to zero. Press "B" once to return to Normal Time Mode.

BJ3463 - SR9031



Toggling through All Modes

- Press "B" to toggle through modes in the following order: Normal Time/Alarm/Stopwatch/Time Setting

EL Backlight

- In any mode, press "C" to illuminate the display for 3 seconds.

12/24 Hour Format

- In Normal Time Mode, press "D" to switch between 12/24H time formats.

Setting the Time and Calendar

1. Toggle to Time Setting Mode, press "D" to seconds will flash.
2. Press "D" to reset the seconds.
3. Press "C" to select settings in the following order: Hour/Minutes/ Month/Day/Day of Week, then press "D" to increase the number.
4. Once complete, press and hold "B" to exit Time Setting Mode.

Setting the Alarm

1. In Alarm Mode, press "D" to turn Alarm and Chime ON/OFF.
2. In Alarm Mode, press "C", hours will flash indicating Alarm Setting Mode.
3. Press "D" to increase the hour.
4. Press "C" to select minutes, and press "D" to increase the number.
5. When all alarm settings are complete, press "C" to confirm and "B" to return to Normal Time Mode.

Stopwatch

1. In Stopwatch Mode press "D" to start the stopwatch, press "D" again to stop.
2. Press "C" to reset to zero.
3. To count Split Time while in Stopwatch Mode with Stopwatch running, press "C".
4. To exit Split Time and stop counting, press "D"
5. To run Stopwatch in background while in Normal Time Mode, press "D" to start Stopwatch, then "B" to return to Normal Time Mode.
6. Press "D" to stop the Stopwatch, then again to reset to zero.

CRH258 IM SR2102, SR2103



Toggling through All Modes

- Press "B" to toggle through all modes in the following order: Real Time/Alarm/Stopwatch/Time Setting

EL Backlight

- In any mode, press "A" to illuminate the display for 3 seconds.

Real Time

- In Real Time Mode, use "C" to toggle between 12 Hour and 24 Hour Format. "24H" will illuminate when in 24 Hour Format. It will be blank when in 12 Hour Format.

Chronograph Stopwatch

- Lap Time
 - In Stopwatch Mode, press "C" to start the stopwatch.
 - Press "C" again to stop the stopwatch.
 - Press "D" to reset the stopwatch to zero.
- Split Time
 - In Stopwatch Mode, press "C" to start the stopwatch.
 - Press "D" to display the split time, the stopwatch will continue in the background.
 - Press "D" again to clear the split time and continue to time measurement.
 - Repeat steps 2 & 3 above to see multiple split time measurements.
 - Press "C" to stop the stopwatch.
 - Press "D" to reset the stopwatch to zero.

Alarm & Hourly Chime

- Before entering Time Setting Mode, in Real Time Mode, use "C" to toggle between 12 Hour and 24 Hour Format. Continue to Alarm Setting Mode to set time in selected format.
- In Alarm mode, press "D" to enter Alarm Setting Mode. "Hour" will begin to flash.

- Press "C" to increase the hour, press and hold to increase at a faster speed.
- Press "D" to select the Minutes.
- Press "C" to increase the Minutes, press and hold to increase at a faster speed.
- Press "D" again to set Alarm Time.
- When Hours and Minutes are no longer flashing, press "C" to toggle between Only Alarm On, Only Chime On, Both Alarm & Chime On, All Off modes. Icons will illuminate when pressed.

- Alarm: 

- Chime: 

- Press "B," "C," or "D" to mute Alarm.
- When Chime is on, sound will chime on the hour.

Stopwatch

1. In Stopwatch Mode press "D" to start the stopwatch, press "D" again to stop.
2. Press "C" to reset to zero. Press "B" once to return to Normal Time Mode.

Time Setting

- Before entering Time Setting Mode, in Real Time Mode, use "C" to toggle between 12 Hour and 24 Hour Format. Continue to Time Setting Mode to set time in selected format.
- In Time Setting Mode, "Second" will be flashing when entered.
- Press "C" to zero.
- Press "D" to select item in the following order: Seconds – Hour – Minute – Month – Date – Day of Week.
- Press "C" to increase the flashing item. Press and hold to increase at a faster speed.
- Repeat steps above until time is set.
- Press "B" to return to Real Time Mode.

CRH921 - SR5132, SR5133



Toggle through All Modes

- Press "B" to toggle through all modes in the following order: Time/ Stopwatch/ Alarm/Time Setting

EL Backlight

- Press "A" to illuminate the display for 3 seconds.

Setting the Time and Calendar

1. In Time Setting Mode, press "D" to reset seconds to "00".
2. Press "C" to select settings in the following order: Second/Hour/Minute/Month/Date/Day of Week (when setting the Hour, "H" will appear in 24Hour format, and "A" and "P" will appear for 12Hour format.)
3. Press "D" to advance each selection.
4. When all settings are complete, press "B" to confirm.

Setting the Alarm

1. In Alarm Mode, press "D" to toggle through Alarm/Chime ON/OFF settings.
2. In Alarm Mode, press "C" to select "Hour" or "Minute" and "D" to advance the setting. Press "B" to confirm.
3. When Alarm sounds, press "C" or "D" to stop it, press "B" to snooze and alarm symbol will flash. (When Snooze is ON, Alarm will sound 5 minutes later, and stop after 20 seconds.)

Stopwatch

1. In Stopwatch Mode, press "D" to Start/Stop, then press "C" to reset.
2. To enter Split Time, press "C" while Stopwatch is running, then press "D" to exit Split Time and stop counting.

3. Press "C" to display all count records, and then press "C" again to reset Stopwatch.
4. To operate Stopwatch in the background, press "B" while counting.

HFT-3447- SR6175, SR6184



Real Time Mode

- Press "B" to toggle through all modes in the following order: Real Time/Stopwatch/Alarm/Time Setting
- In Real Time Mode, press "D" to display Calendar.
- In Real Time Mode, Press "C" to display Alarm Time.

EL Backlight

- In any mode, press "A" to illuminate the display for 3 seconds.

Time Setting




- In Real Time Mode, press "B" three times to enter Time Setting Mode.
- In Time Setting Mode, "Second" will be flashing when entered.


- Press "D" to zero.
- Press "C" to select item in the following order: Minute – Hour – Date – Month – Day of Week – Seconds.
- Press "D" to increase the flashing item. Press and hold to increase at a faster speed.
- 12/24 Hour formats can be selected during Time Setting Mode. When setting the Hour, "H" will be shown for 24-hour format, "A" or "P" for 12-hour format.
- Repeat steps above until time is set.
- Press "B" to return to Real Time Mode.

Alarm

- In Real Time Mode, press "B" two times to enter Alarm Setting Mode.
- Press "C" to select Hour or Minute.
- Press "D" to adjust flashing item.
- Press "C" to confirm setting.
- Press "B" to return to Real Time mode once alarm is set.

Alarm & Hourly Chime Setting

- In Real Time Mode, to turn Alarm on, press and hold "C" and press "D" once. Alarm icon  will show in display.
- To turn Alarm off, press and hold "C" and press "D" once. Alarm icon  will disappear.
- To turn Chime on, press and hold "C" and press "B" once. Chime icon  will show in display.

- To turn Chime off, press and hold "C" and press "B" once. Chime icon  will disappear.
- Chime indicator will be set for all 7 days of the week.
- In Real Time Mode, press "C" to display settings for Alarm and Chime.

Alarm Snooze On/Off

- When Alarm is sounding, press "C" or "D" to stop sound.
- To Snooze, press "D." This will cause the Alarm to sound again in 5 minutes time.
- The Alarm will stop sounding after approximately 60 seconds.

Chronograph Stopwatch

- In Real Time Mode, press "B" one time to enter Chronograph Mode.
- Press "D" to Start/Stop Chronograph.
- When stopped, press "C" to reset to zero.
- While running, press "C" to split the count. Press "C" again to exit split count and resume Chronograph.
- While stopped in Split Count Mode, press "D" to exit split count and stop counting. Then press "C" to show the total counts. Press "C" again to reset to zero.
- In Chronograph Mode, press "B" to return to Real Time Mode and the Chronograph will run in the background.

HFT-3450 – SR6185, SR6186, SR6187



toggling through All Modes

- Press "B" to toggle through all modes in the following order: Real Time/Stopwatch/Alarm/Time Setting

EL Backlight

- In any mode, press "A" to illuminate the display for 3 seconds.

Time Setting



- In Real Time Mode, press "B" three times to enter Time Setting Mode.
- In Time Setting Mode, "Second" will be flashing when entered.
- Press "D" to zero.
- Press "C" to select item in the following order: Hour – Minute – Month – Date – Day of Week – Seconds.
- Press "D" to increase the flashing item. Press and hold to increase at a faster speed.

- 12/24 Hour formats can be selected during Time Setting Mode. When setting the Hour, "H" will be shown for 24-hour format, "A" or "P" for 12-hour format.
- Repeat steps above until time is set.
- Press "B" to return to Real Time Mode.

Alarm

- In Real Time Mode, press "B" two times to enter Alarm Setting Mode.
- Press "C" to select Hour or Minute.
- Press "D" to adjust flashing item.
- Press "C" to confirm setting.
- Press "B" to return to Real Time mode once alarm is set.

Alarm & Hourly Chime Setting

- In Alarm Time Mode, press "D" to turn on Alarm. Alarm icon  will show in display.
- Press "D" again to turn on Hourly Chime. Chime icon  will show in display.
- Press "D" again to turn on both Alarm and Hourly Chime. Both icons will show in display.
- Press "D" again to turn off both Alarm and Hourly Chime. No icons will be displayed.
- When finished with settings, press "B" to return to Real Time Mode.

Alarm Snooze On/Off

- When Alarm is sounding, press "C" or "D" to stop sound.

- To Snooze, press "B." This will cause the Alarm to sound again in 5 minutes time.
- The Alarm will stop sounding after approximately 20 seconds.

Chronograph Stopwatch

- In Real Time Mode, press "B" one time to enter Chronograph Mode.
- Press "D" to Start/Stop Chronograph.
- When stopped, press "C" to reset to zero.
- While running, press "C" to split the count. Press "C" again to exit split count and resume Chronograph.
- While stopped in Split Count Mode, press "D" to exit split count and stop counting. Then press "C" to show the total counts. Press "C" again to reset to zero.
- In Chronograph Mode, press "B" to return to Real Time Mode and the Chronograph will run in the background.

HFT-3474 - SR6193, SR6194, SR6195



Toggle through All Modes

- Press "B" to toggle through all modes in the following order: Time/ Stopwatch/ Alarm/Time Setting

EL Backlight

- Press "A" to illuminate the display for 3 seconds.

Setting the Time and Calendar

1. In Time Setting Mode, press "D" to reset seconds to "00".
2. Press "C" to select settings in the following order: Second/Hour/ Minute/Month/Date/Day of Week (when setting the Hour, "H" will appear in 24Hour format, and "A" and "P" will appear for 12Hour format.)
3. Press "D" to advance each selection.
4. When all settings are complete, press "B" to confirm.

Setting the Alarm

1. In Alarm Mode, press "D" to toggle through Alarm/Chime ON/ OFF settings.
2. In Alarm Mode, press "C" to select "Hour" or "Minute" and "D" to advance the setting. Press "B" to confirm.
3. When Alarm sounds, press "C" or "D" to stop it, press "B" to snooze and alarm symbol will flash. (When Snooze is ON, Alarm will sound 5 minutes later, and stop after 20 seconds.)

Stopwatch

1. In Stopwatch Mode, press "D" to Start/Stop, then press "C" to reset.
2. To enter Split Time, press "C" while Stopwatch is running, then press "D" to exit Split Time and stop counting.
3. Press "C" to display all count records, and then press "C" again to reset Stopwatch.
4. To operate Stopwatch in the background, press "B" while counting.

STANDARD LIMITED WARRANTY

The Skechers Two (2) Year Limited Warranty is a voluntary manufacturer's warranty. It provides rights separate to rights provided by consumer law, including but not limited to those relating to non-conforming goods. Skechers's limited warranty benefits are in addition to, and not instead of, rights provided by consumer law.

Your Skechers watch is warranted by Fossil Group, Inc* ("Fossil") for a period two (2) years from the original date of purchase under the terms and conditions of this warranty. The Skechers warranty covers materials and manufacturing defects. A copy of the receipt or dealer stamp in the warranty booklet is required for proof of purchase.

During the warranty period the watch movement, hands and dial are the only components covered under this warranty. A covered component will be repaired or the watch will be replaced free of component and labor charges, if it proves to be defective in material or workmanship under normal use.

In case of replacement, Fossil cannot guarantee that you will receive the same model watch. If your model is not available, a watch of equal value and similar style will be provided. The warranty for the replacement watch ends two (2) years from the date the replacement watch is received.

THIS WARRANTY DOES NOT COVER:

- Any defects in materials and workmanship of battery, case, crystal, strap or bracelet; including plating on the case and/or bracelet.

- Damage resulting from improper handling, lack of care, accidents, normal wear and tear or aging.
- Water damage if care instructions for the product's water resistance level (as marked on the product) were not followed.
- Products that are not purchased from an authorized Skechers retailer.

This warranty is void if the watch has been damaged by accident, negligence of persons other than authorized Fossil sales or services agents, unauthorized service, or other factors not due to defects in materials or workmanship. The warranty is void if the serial numbers or product date codes or other tracking marks have been removed, altered or obliterated.

If not stated otherwise, the foregoing warranties and remedies are exclusive and in lieu of all other warranties, terms or conditions, express, implied or statutory, as to any matter whatsoever, including, without limitation, warranties of merchantability, fitness for a particular purpose, accuracy, satisfactory quality, title, and non-infringement, all of which are expressly disclaimed by Fossil. Fossil shall not be liable for incidental, consequential, indirect, special or punitive damages or liabilities of any kind arising out of or in connection with the sale or use of this product, whether based in contract, tort (including negligence), strict product liability or any other theory, even if Fossil has been advised of the possibility of such damages and even if any limited remedy specified herein is deemed to have failed of its essential purpose. Fossil's entire liability shall be limited to replacement or repair of the purchase price paid, at Fossil's sole option.

Some countries, states, or provinces do not allow the exclusion or limitation of implied warranties or the limitation of incidental or consequential damages so the above limitations and exclusions may be limited in their application to you. When implied warranties may not be excluded in their entirety, they will be limited to the duration of the applicable written warranty. This warranty gives you specific legal rights; you may have other rights that may vary depending on local law. Your statutory rights are not affected.

REQUESTING WARRANTY AND OTHER WATCH REPAIR:

Should you require work under warranty, please send in your watch, a copy of your sales receipt and/or the warranty booklet with dealer stamp and a description of the problem to the authorized international watch service center closest to you. Visit www.fossilgroup.com.

For service work that is not covered under this warranty, the service center may perform the services you request for a charge dependent on watch style and type of work requested. These charges are subject to change.

Do not send original packaging, as it will not be returned. Fossil highly recommends you insure your parcel and adequately protect the watch during shipment. Fossil is not responsible for product lost or damaged during shipment.

*901 South Central Expressway, Richardson, Texas 75080 USA

For watch instructions or further information, please visit us at <https://www.skechers.com/en-us/watch-instructions> or call 1-800-842-8621

Water Resistance

See caseback for water resistance rating.

The water resistance rating provides guidelines for appropriate water-related exposure to avoid damage to internal watch components. Please see chart for recommended usage guidelines.

In order to ensure water does not enter the watch and cause damage to it, please follow the instructions listed below:

- Do not adjust the crown while the timepiece is in contact with water.
- Ensure the crown is in the closed position before contact with water. For timepieces with screw-down crowns, ensure the crown is completely tightened before contact with water.
- For timepieces with pusher-enabled functionality, do not engage the function underwater.
- Exposure to extreme atmospheres is not recommended (i.e. hot water, saunas or steam rooms).
- Avoid exposure to water moving with force (i.e. water running from a faucet, ocean waves or waterfalls).
- Avoid long exposure to salt water. After contact with salt water, rinse watch under tap water if rated 5ATM or higher and wipe dry with a soft cloth.

RECOMMENDATIONS FOR WATER-RELATED USE

INDICATION				
	Hand Washing	Shower/Bathing	Swimming/Snorkeling	Scuba Diving
(NONE)				
WR	✓			
3 ATM • 3 BAR • 30 Meters	✓			
5 ATM • 5 BAR • 50 Meters	✓	✓		
10 ATM • 10 BAR • 100 Meters	✓	✓	✓	
20 ATM • 20 BAR • 200 Meters	✓	✓	✓	✓

Authorized Skechers Service Centers

AUSTRIA

DHL Express (Austria) GmbH
Fossil Repairs Service
Gewerbestrasse 9
A- 5102 Anthering
T: 0810 300 450
E: service@fossil.de

AUSTRALIA

Fossil Australia Focus Building,
Level 3
F24 122-126 Old Pittwater
Road
Brookvale NSW 2100
Australia
T: 02 94530288
F: 02 9453 0299
E: customercare.au@fossil.com

BELGIUM / LUXEMBOURG

DHL
Attn. Warranty & Repairs
Woluwelaan 151
1831 Diegem
T: +31 (0) 31 479 90 62
E: customerservice@fossil.nl

BRAZIL

Grupo Technos
Rua Julio Gonzalez, number
132, 27th floor
Barra Funda
São Paulo 01156-060
T: +55 (11) 3003-1070
E: sac@grupotechnos.com.br

CANADA

FG Services - Attn: Repairs
C/O NFI
25 Cottrelle Boulevard, Unit 3
Brampton, Ontario, L6S0C3,
Canada
T: 1-800-699-0556
E: info.ca@fgservices.com

CHILE

Establecimientos California
SERTEC
Attn: Carlos Rosales (manager)
and Maria Estelia Nuñez
Av.11 de Septiembre 2260
Local 130, Providencia
Santiago, Chile
T: (56-2) 29394035 (56-2)
29394035 (56-2) 29394038
E: serviciotecnico@california.cl
E: crosales@california.cl
E: mnunez@california.cl

CHINA

Fossil Trading (Shanghai)
Co. Ltd.
Rm 2504, 25/F Grand Gateway
Tower II
3 Hong Qiao Road
Xu Hui District, Shanghai
200030, China
T: (86)400-820-3126
E: shanghaicustomerservice-
group2@fossil.com

CHINA

Fossil Hong Kong Limited
17/F, CDW Building
388 Castle Peak Road
Tsuen Wan, New Territories
Hong Kong SAR, China
T: (852) 3008 2157
E: FossilAsia-AfterSales@
fossil.com

CHINA - MACAU

Fossil Hong Kong Limited
17/F, CDW Building
388 Castle Peak Road
Tsuen Wan, New Territories
Hong Kong SAR, China
T: (852) 3008 2157
E: FossilAsia-AfterSales@
fossil.com

COLOMBIA

TSQ S.A - Servicio Tecnico
Centro Comercial Hacienda
Contact Person: Adriana
Sanchez - (TSQ)
Calle 114# 6A - 92 local C-235,
Santa Barbara
T: 2132688, 6121837
E: serviciotecnicohsb@
tsqsa.com
E: asanchez@tsqsa.com

COSTA RICA

Guialsa S.A.
Attn: Juan Carlos
200 Metros Norte del INA en
Paseo Colon
San Jose, Costa Rica
T: 222-0804
T: 2256-5716
T: 2257-2349
E: guialsa@polarcr.com

CROATIA

Hora Plus D.O.O.
Vlaska 55
10000 Zagreb
Croatia
T: +385 1 4697 787
E: Ivana@horaplus.hr

DENMARK

FairTrans
C/O FAST EUROPE
Kliplev Erhvervspark 20, Kliplev
Vigtig: Indlevering på kontor
– 1 sal.
DK-6200 AABENRAA
T: +45 45 88 34 60
E: salesdenmark@fossil.com

ECUADOR

Distribuidora Yabimodas
Av. Shyris N36-188 y Naciones
Unidas
Edf. Shyris Park, Ofc 409
Quito, Ecuador
T: (593) 2 292 6119
E: gerenciacomercial.ec@
yabimodas.com

FRANCE

SAV Fossil France
Rue du Martelberg
BP 80023 Monswiller
67701 Saverne Cedex
T: +33 3.88.02.52.52
E: contact@fossil.fr

GERMANY

FESCO GmbH
Service DHL Logistiklager/ LDB
Werkstrasse 17
D-77815 Bühl
T: +49 8661 – 622 6054
E: service@fossil.de

GUATEMALA

Watch it!
Diagonal 6, 13-01 zona 10
Oakland Mall
Tercer nivel
Guatemala
T: +502 4220 5778
E: serviciotecnico@victorino.gt

HONDURAS

Centro Tecnico Relojero
Centro Comercial Metroplaza
1er nivel de tiendas, local no.
5, Cortes
San Pedro Sula, Honduras
T: 504 2580 2221
E: rpineda@zaredjoyeros.com
E: centecrelojero@zaredjoy-
eros.com
E: centecrelojero@ontimehn.
com

INDIA

Fossil India Pvt. Ltd.
621, 12th Main
HAL II Stage, Indiranagar
Bangalore 560 008
India
T: +18604253747
E: service.in@fossil.com

INDIA

Fossil India Pvt. Ltd.
Shop G18, Orion Mall
Dr. Raj Kumar Road, Rajaji
Nagar
Bangalore 560 055
Karnataka
India
T: 080-22682245
E: serviceorion@fossil.com

INDIA

Fossil India Pvt. Ltd.
Shop No. 116, DLF Prome-
nade Mall
Nelson Mandela Marg,
Vasant Kunj
New Delhi 110 070
India
T: 011-41664015
T: 011-41664016
E: service_3874@fossil.com

INDIA

Fossil India Pvt. Ltd.
Shop No. S010, Ground Floor
Express Avenue Mall, Plot
No.213, Whites Road
Royapettah
Chennai 600 014
Tamil Nadu
India
T: 044-28464288
E: service_3831@fossil.com

INDIA

Fossil India Pvt. Ltd.
Shop No. G10, Ambience Mall
Delhi - Jaipur Expy, Ambience
Island
DLF Phase 3, Sector 24
Gurgaon 122 010
Haryana
India
T: 0124-4665529
E: service_3834@fossil.com

IRELAND

Transalliance TS
FAST (Fossil After Sales Team)
- Suite 8-9
Faraday Court - Centrum 100 -
Burton Upon Trent
DE14 2WX Staffordshire
T: +44 0344 412 3277
E: ukenquiries@fossil.com

ITALY

FAST Europe
C/O DHL Supply Chain
Corso Lombardia N.61
10099 San Mauro Torinese
(TO)
T: +39 0694 802651
E: online@fossil.it

JAPAN

Fossil Japan Repair Center
Yasuda A building 2F, 3-9
Moriya-cho Kanagawa-ku
Yokohama, 221-0022
T: (81) 03 4579 0368
F: (81) 45 450 6243
E: shop.jp@fossil.com

MALAYSIA

Fossil Time Malaysia - Service
Centre
Unit L2-2-7, 2nd Floor
Wisma Kemajuan
No.2 Jalan 19/1B
46300 Petaling Jaya, Selangor
T: 03-7969 1900
E: fmycs@fossil.com

MEXICO

Metro Service Center México
Carretera Monterrey - Saltillo
1249 - A
Col. Pio XII
Santa Catarina, N.L. Mexico
C.P. 66362
T: 01 800 236 7745
E: reparaciones@fossil.com

NEW ZEALAND

Watch World Ltd
45a Arrenway Drive
Albany
Auckland
T: 09 475 6103

PANAMA

Z Relojero
C/Samuel Lewis
Panama
T: 00507-3006666
E: servicioalcliente@relojin.com
E: gerente@relojin.com

PERU

Le Grand Montres & Bijoux
Av Risso # 243
Oficina 202, Lince - Técnico,
Jose Muñoz
Lima, Peru
T: (+51) 935 508 416
E: peru.legrand@gmail.com

POLAND

FAST
C/O Expeditors Polska
Św. Tomasza 4D
05-808 Parzniew
T: +48 22 574 28 88
E: fgservicespl@fossil.com

PORTUGAL

Expeditors Portugal C/O
Espaçotrans
Att Reparações Fossil (FAST)
Parque Logístico Marinhas
de D. Ana
Quebradas de Cima, Armazém
6, 2625-090 Póvoa de
Santa Iria
T: 214232000
E: customerservice.pt@
fossil.com

SINGAPORE

Fossil Singapore Pte Ltd
51 Bras Basah Road
#08-07 Manulife Centre
Singapore 189554
T: (65) 3165 4961
E: customerservice.sg@
fossil.com

SOUTH KOREA

Fossil (Korea) Limited
5F M Tower
29, Teheran-ro 87-gil,
Gangnam-gu
Seoul, Korea
T: 82 2 3440 6400

SPAIN - PENINSULA

Expeditors ZAZ
c/o FAST EUROPE (REPAIRS)
C/ Los Ángeles nº 15, Nave 10
Polígono Industrial Centrovía
50198 La Muela (Zaragoza)
T: +34933633870
E: customerservice.es@
fossil.com

SURINAME

Timeless Jewelry, N.V
Attn: Ms. Inisrah Ashruf
Johannes Mungrastraat 17
Paramaribo
T: 597 473998
E: inisrah.ashruf@timelessnv.
com

SWEDEN

Aditro Logistics AB
c/o FAST Europe
Prognosgatan 1
50464 Borås
T: (+46) 31 719 45 00
E: servicecenter@fossil.com

**UNITED STATES OF
AMERICA**

Metro Service Center -
Attn: Repairs
10615 Sanden Drive Dallas
Texas 75238-1720 T: 800-
842-8621
E: service@metroser-
vicecenter.com

Certificate of Warranty

The CERTIFICATE OF WARRANTY which follows below is to be completed at time of purchase by the retail store where you purchased your watch.

Model Number:

Country/Date:

Sold To:

Vendor Stamp:

Sold By:

Notices



DISPOSAL OF OLD ELECTRICAL AND ELECTRONIC EQUIPMENT

The symbol indicates that this product shall not be mixed with unsorted municipal waste when disposed of. There is a separate collection system for waste electrical and electronic equipment. Usually old electrical and electronic equipment can be returned free of charge. For further information please contact the competent municipal authorities or the shop where you purchased the product. Correct disposal ensures that waste electrical and electronic equipment is recycled and reused appropriately. It helps avoid potential damage for the environment and human health and to preserve natural resources.



ENGLISH: Certain watch styles are fitted with lithium batteries which may contain perchlorate material - special handling may apply, see www.dtsc.ca.gov/hazardouswaste/perchlorate for more information.

ENGLISH: Any diamonds used in our products have been purchased from legitimate sources not involved in funding conflict and in compliance with United Nations resolutions. We hereby guarantee that these diamonds are conflict free, based on personal knowledge and/or written guarantees provided by the supplier of these diamonds.

